




EN

CHEST FREEZER

USER MANUAL



Warning:
Before using this product,
please read this manual carefully
and keep it for future reference.
The design and specifications
are subject to change without
prior notice for product
improvement. Consult with your
dealer or manufacturer for
details.

version:003-8-2021

**MODEL: MDRC207FZF01AP
MDRC280FZF01AP**

www.midea.com

Dear user

THANK YOU and **CONGRATULATIONS** on your purchase of this high-quality Midea product. Your Midea chest freezer is designed for reliable, trouble-free performance.

For future reference, please record your product model and serial number on the back of the product or above the compressor compartment on the right.

Model Number _____

Serial Number _____

1.SAFETY INFORMATION	3
2.PROPER USE OF CHEST FREEZER.....	11
2.1 PLACEMENT.....	11
2.2 ENERGY SAVING TIPS	11
2.3 CHANGING THE LIGHT (OPTIONAL)	12
2.4 START TO USE.....	12
2.5 COMPONENTS	13
2.6 TEMPERATURE CONTROL	14
3.MAINTENANCE OF CHEST FREEZER	15
3.1 CLEANING	15
3.2 DEFROSTING.....	16
3.3 NON-USE	16
4.TROUBLE SHOOTING.....	17

1. SAFETY INFORMATION

YOUR SAFETY AND THE SAFETY OF OTHERS ARE VERY IMPORTANT

To prevent injury to the user or other persons and property damage, these instructions must be followed. Incorrect operation due to ignoring instructions may cause harm or damage, including death.

The level of risk is shown by the following indications.



Prohibition symbol

This is a prohibition symbol.

Any in compliance with instructions marked with this symbol may result in damage to the product or endanger the personal safety of the user.



Warning symbol

This is a warning symbol.

It is required to operate in strict observance of instructions marked with this symbol; otherwise damage to the product or personal injury may be caused.



Cautioning symbol

This is a cautioning symbol.

Instructions marked with this symbol require special caution. Insufficient caution may result in slight or moderate injury or damage to the product.

IMPORTANT SAFETY INSTRUCTIONS



Risk of fire / Flammable materials

WARNING

- This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.



- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- The appliance has to be unplugged after use and before carrying out user maintenance.
- **WARNING:** Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstructions.
- **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **WARNING:** Do not damage the refrigerant circuit.
- **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- **WARNING:** Please dispose of the chest freezer according to local regulations since it uses flammable blowing gas and refrigerant.
- **WARNING:** When positioning the appliance, ensure the supply cord is not trapped or damaged.
- **WARNING:** Do not place multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- **WARNING:** Do not use extension cords or ungrounded (two prong) adapters.
- **WARNING:** To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- To Prevent Children From Being Entrapped, The Keys Must Be Kept Out Of Reach Of Children And Not In The Vicinity Of Chest Freezer (Or Refrigerator) (suitable for products with locks).





DANGER

- Risk of child entrapment. Before you dispose of your old refrigerator or chest freezer:
 - Take off the doors.
 - Leave the shelves in place so that children may not easily climb inside.
- The chest freezer must be disconnected from mains power before attempting the installation of accessories.
- Refrigerant and cyclopentane foaming material used for the appliance are flammable. Therefore, when the appliance is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.
- For doors or lids fitted with locks, the keys must be kept out of reach of children and not in the vicinity of the chest freezer appliance, in order to prevent children from being locked inside.

Safety
Information

Proper Use of
Chest Freezer






Maintenance of
Chest Freezer

Trouble
Shooting

Appendix

WARNING


For EU standard:

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
 - To avoid contamination of food, please observe the following instructions:
 - Opening the door for long periods of time can cause a significant increase of the temperature in the compartments of the appliance.
 - Clean regularly surfaces that can come in contact with food and accessible drainage systems.
 - Clean water tanks if they have not been used for 48 hours; flush the water system connected to a water supply if water has not been drawn for 5 days. (Note 1)
 - Store raw meat and fish in suitable containers in the chest freezer, so that it is not in contact with or drip onto other food.
 - Two-star  frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes. (Note 2)
 - One-star , two-star  and three-star  compartments are not suitable for freezing fresh food. (Note 3)
 - For appliances without a 4-star  compartment: this refrigerating appliance is not suitable for freezing foodstuffs. (Note 4)
 - If the refrigerating appliance is left empty for long periods of time, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Notes 1, 2, 3, 4: Please confirm whether it is applicable according to your product.
- For a freestanding appliance: this refrigerating appliance is not intended to be used as a built-in appliance.
 - Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified persons.

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

State of California Proposition 65 Warnings:

 **WARNING:** Cancer and Reproductive Harm
-www.P65Warnings.ca.gov.

PROPER DISPOSAL

WARNING

Suffocation Hazard

Before you dispose of your old chest freezer or refrigerator:

- Remove the door or lid so that children cannot hide or get trapped inside your old appliance.
- Leave any shelves in place so that children may not easily climb inside.
- Failure to follow these instructions can result in death or brain damage.

IMPORTANT:

Flammable gas and refrigerant used. It is the consumer's responsibility to comply with Federal and Local regulations when disposing of this product. Refrigerants must be evacuated by a licensed, EPA-certified refrigerant technician in accordance with established procedures.

Safety
Information

Proper Use of
Chest Freezer

Maintenance of
Chest Freezer


Trouble
Shooting

Appendix




ELECTRICITY-RELATED WARNINGS

- Do not pull the power cord when pulling the power plug of the chest freezer. Please firmly grasp the plug and pull out from the socket.
- Do not damage the power cord under any condition. To ensure safe use, do not use when the power cord is damaged or the plug is worn.
- Worn or damaged power cord Must be replaced by the manufacturer or his service center.




- The power plug should be firmly in contact with the socket; otherwise fire may be caused. Please ensure that the appliance is properly grounded.
- Please turn off the valve of leaking gas and open the doors and windows in case of leakage of gas and other flammable substances. Do not unplug the chest freezer and other electrical appliances considering that spark may cause a fire.



- To ensure safety, it is not recommended that to place regulators, rice cookers, microwave ovens and other appliances on top of the chest freezer, unless they are of the type recommended by the manufacturer. Do not use electrical appliances inside the food storage compartments of the appliance.

WARNINGS RELATED TO PLACING ITEMS

- Do not place flammable, explosive, volatile and highly corrosive items in the chest freezer to prevent damages to the product or fire accidents.
- Do not place flammable items near the chest freezer to avoid fires.




- This product is a household chest freezer and is only suitable for storing food. According to national standards, household chest freezers shall not be used for other purposes, such as storage of blood, drugs or biological products.
- Do not place items such as bottled or sealed fluid container such as bottled beer and beverages in the chest freezer to prevent bursts and other losses.




WARNINGS FOR USE

- Do not arbitrarily disassemble or reconstruct the chest freezer, nor damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist.
- A damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.




- The gaps between chest freezer lid and body are small. Do not place your hands in these areas to prevent squeezing your fingers. Please be gentle when open the chest freezer door to avoid articles falling out.
- Do not pick up food or containers with wet hands in the freezing chamber when the chest freezer is running, especially metal containers in order to avoid frostbit.



- Do not allow children to enter or climb in the chest freezer to prevent that they are sealed in the chest freezer or injured by the falling chest freezer.
- Do not spray or wash the chest freezer; do not place the chest freezer in moist places easy to be splashed with water not to affect the electrical insulation properties of the chest freezer.



- Do not place heavy objects on top of the chest freezer considering that objects may fall when opening the door and injuries might be caused.
- Please pull out the plug in case of power failure or cleaning. Do not connect the chest freezer to mains power supply within five minutes to prevent damages to the compressor due to successive starts.





ENERGY WARNINGS

- 1.** The chest freezer may not operate consistently when set for an extended period of time below the cold end of the temperature range for which the chest freezer is designed.
- 2.** Sparkling beverages shall not be stored in a chest freezer or a lower temperature compartment. Certain drinks (such as ice water) shall not be too cold for drinking.
- 3.** Do not exceed the storage time recommended by the food manufacturers for any kind of food and particularly for commercially quick-frozen food in food-freezer and frozen-food storage compartments or cabinets
- 4.** Prevent an undue rise in temperature of frozen food while defrosting the refrigerating appliance, such as wrapping the frozen food in several layers of newspaper.
- 5.** A rise in temperature of frozen food during manual defrosting, maintenance or cleaning can shorten the storage life.

DISPOSAL



The chest freezer's refrigerant and cyclopentane foam materials are combustible materials and discarded chest freezers should be isolated from fire sources and are not to be burned. Please hand the chest freezer to a qualified professional recycling company for processing to avoid damages to the environment or other hazards.



Please remove the door of the chest freezer. Shelves should be properly placed to avoid accidents of children entering and playing in the chest freezer.

Correct Disposal of this product:





This marking indicates that this product should not be disposed with other household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They take this product in for environmental safe recycling.




2. PROPER USE OF CHEST FREEZER

2.1 PLACEMENT


- Before using the chest freezer, remove all packaging materials including bottom pads, foam pads and tape inside the chest freezer, tear off the protective film on the door and the chest freezer body.
- The space on top of the chest freezer shall be greater than 70cm, and the chest freezer should be placed against a wall with a distance of more than 20cm to facilitate heat dissipation.



- Keep away from heat and avoid direct sunlight. Do not place the chest freezer in moist or wet places to prevent rust or reduction of the insulating effect.



- The chest freezer should be placed in a well-ventilated indoor place; the ground must be flat, and sturdy.




2.2 ENERGY SAVING TIPS

- The appliance should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of direct sunlight.
- Let hot foods cool down to room temperature before placing it in the appliance. Overloading the appliance forces the compressor to run longer. Food that freezes too slowly may lose quality, or spoil.
- Be sure to wrap food properly, and wipe containers dry before placing them in the appliance. This cuts down on frost build-up inside the appliance.
- Appliance storage bins should not be lined with tin foil, wax paper, or paper toweling. Liners interfere with cold air circulation, making the appliance less efficient.

- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

2.3 CHANGING THE LIGHT (OPTIONAL)

- Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified persons.



The light source in this product is only to be replaced by qualified engineers.


- Disconnect the power supply before carrying out bulb replacement, hold to remove the light bulb cover.
- Dismantle the old bulb by unscrewing it counter-clockwise. Replace with a new bulb (max 15W) by screwing it in clockwise, and make sure it is fixed in the bulb holder tightly.
- Reassemble the light cover and re-connect your chest freezer to power supply.

IMPORTANT:


The text above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

2.4 START TO USE

- The chest freezer should stay for two hours before connecting power.
- The chest freezer should run 2 to 3 hours before loading fresh or frozen food; the chest freezer should run for more than 4 hours in summer in advance considering that the ambient temperature is high.



2.5 COMPONENTS



The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

- The low temperature of chest freezer may keep food fresh for a long time and it is mainly used to store frozen food and making ice.
- The chest freezer is suitable for storing meat, fish, shrimps, pastries and other food not to be consumed in the short term. Do not store fluids in bottled or closed containers such as bottled beer, beverages, etc.
- Please note that food should be consumed within the shelf life.
- Freezing capacity value is marked on the rating label. The freezing speed of the product is related to the amount of food stored and the ambient temperature. If you place too much normal temperature food in one time, you need to adjust the chest freezer to the maximum setting and power on 24 hours in advance. Large size food should be divided into small size for storage, otherwise it cannot be frozen completely and might cause bad.

IMPORTANT:


After long-term use, there may be a certain degree of wear of the hinges. This will cause a noise when opening/closing the door and reduce the service life of hinge. It is recommended to grease the hinges regularly to effectively eliminate noise and extend the service life of hinges.

The weight of the objects in the basket should not exceed 5kg.

If the product is packaged in thin film, there may be condensation on the surface of the box and the film when the temperature and humidity of the transportation environment changes rapidly.

This is a normal physical phenomenon and does not affect the use of the product.

2.6 TEMPERATURE CONTROL



- Connect the chest freezer to mains power, the “POWER” indicator will light up (green light).
- Turn the thermostat knob clockwise for the temperature inside the chest freezer to decrease.
- “COOLING” means cooling zone, “FREEZING” means the freezing zone.
- “Recommended setting” see marked position
- The coldest gear can quickly freeze food in a short period of time. If a large amount of food is frozen at the same time, it is recommended to adjust to the coldest setting 12 hours in advance before adding the food. After the food is quickly frozen, please adjust the gear back to the normal range.

IMPORTANT:

The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

3. MAINTENANCE OF CHEST FREEZER

Your chest freezer is designed for year-round use and requires minimal cleaning and maintenance. To keep your chest freezer running efficiently and odor-free, we recommend that you clean the chest freezer regularly.

3.1 CLEANING

- Dust behind the chest freezer and on the ground should be cleaned to improve the cooling effect and energy saving.
- Check the door gasket regularly to make sure there is no debris. Clean the door gasket with a soft cloth dampened with soapy water or diluted detergent.
- The interior of the chest freezer should be cleaned regularly to avoid bad odors.
- Please turn off the power before cleaning, remove all food, baskets, containers, etc.
- Use a soft cloth or sponge to clean the inside of the chest freezer with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean. After cleaning, open the door and let it dry naturally before turning on the power.
- For areas that are difficult to clean in the chest freezer (such as gaps or corners), it is recommended to wipe them regularly with a soft rag, soft brush, etc. and when necessary, use some auxiliary tools (such as thin sticks) to ensure no contaminant or bacteria accumulation in these areas.

- Do not use soap, detergent, scouring powder, spray cleaner, etc., as these may cause odors in the interior of the chest freezer or contaminate the food.
- Clean the baskets with a soft cloth dampened with soapy water or diluted detergent. Dry with a soft cloth or dry naturally.
- Wipe the outer surface of the chest freezer with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, scouring pads, wire brushes, abrasives (such as toothpaste), organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items, which may damage the chest freezer surface and interior. Boiling water and organic solvents such as benzene may deform or damage plastic parts.
- Do not rinse directly with water or other liquids during cleaning to avoid short circuit or affect electrical insulation after immersion.



Unplug the chest freezer for defrosting and cleaning.

Safety Information

Proper Use of Chest Freezer

Maintenance of Chest Freezer

Trouble Shooting

Appendix



3.2 DEFROSTING

The chest freezer should be manually defrosted.

- Unplug the chest freezer and open the chest freezer door, remove food and baskets before defrosting. Open the drain hole (and place a container at the outlet). Indoor frost will naturally melt, wipe the defrost water with a dry, soft cloth. When the frost softens, an ice scraper might be used to accelerate the de-icing process.
- Please remove the food and put in a cool place when defrosting.



Other mechanical devices or other means should not be used to accelerate defrosting, except those recommended by the manufacturer. Do not damage the refrigerant circuit.

3.3 NON-USE

- Power failure: In case of power failure, even if it is in summer, food inside the appliance can be kept for several hours; during the power failure, the times of opening the doors must be reduced, and no more fresh food should be placed into the appliance.
- Long-time nonuse: Unplug the chest freezer left unused for a long time for cleaning. Keep the door open to avoid bad odors.
- Moving: Do not turn the chest freezer upright or shake it. The carrying angle should not be greater than 45°. Do not hold door and hinges when moving this unit.



Continuous operation is recommended when the chest freezer is started. Do not stop the chest freezer under normal circumstances so as not to affect the chest freezer's service life.

Safety Information

Proper Use of Chest Freezer

Maintenance of Chest Freezer

Trouble Shooting

Appendix



4. TROUBLE SHOOTING

The following simple issues can be handled by the user. Please call the after-sale service department if the issues are not solved.

Malfunction	Check whether the chest freezer is plugged in and connected to power. Low voltage. Check whether the temperature control knob is set properly. Power failure or tripping circuit.
Odor	Odorous food should be closely wrapped. Check if the food is rotten. Check if the interior must be cleaned.
Long-term operation of the compressor	It is normal that the chest freezer operates for a longer time in summer when the ambient temperature is higher. Do not place too much food in the chest freezer at one time. Do not place food in the chest freezer before it has cooled down. Frequent opening of chest freezer door. Thick layer of frost (defrosting is needed).
Light does not work	Check if the chest freezer is connected to mains power or the light is damaged.
Door cannot be properly closed	The chest freezer door is obstructed by food packages. Too much food. Unbalanced chest freezer.
Loud noises	Check if the floor is flat, whether the placement of chest freezer is stable. Check if the chest freezer accessories are properly placed.
Difficulty in door opening	After refrigeration, there will be pressure difference between the inside and outside of the chest freezer that results in difficulty to open the door. This is a normal physical phenomenon.
Hot sidewalls	The chest freezer housing may emit heat during operation especially in summer. This is caused by the radiation of the condenser, and it is a normal phenomenon.
Surface condensation	Condensation: This phenomenon will be detected on the exterior surface and door seals of the chest freezer when the ambient humidity is high. This is a normal phenomenon, and the condensation can be wiped away with a dry towel.
Airflow sound Buzz Clatter	Refrigerants circulating in the pipes will produce sound and grunts which is normal and does not affect the cooling. Buzz will be generated by running compressor especially when starting up or shutting down. The solenoid valve or electric switch valve will clatter which is a normal phenomenon and does not affect operation.

Safety
Information



Proper Use of
Chest Freezer

Maintenance of
Chest Freezer

Trouble
Shooting

Appendix

WHEEL INSTALLATION INSTRUCTIONS (OPTIONAL)



Safety
Information

Proper Use of
Chest Freezer


Maintenance of
Chest Freezer

Trouble
Shooting

Appendix



7. Remove the screw with screwdriver.



8. Reuse the screw that was removed in the previous step, and fix the caster with the screws from the box.



9. After completed installation.



10. Stand the chest freezer up again (keep the chest freezer standing up for more than 6 hours before connectin to mains power supply.)



11. Secure the handle on the door.



12. Place two ends of the handle cover into the slot, then push the middle of the cover to complete.



Midea
Make yourself at home