

Safe use of rules

Must by adults on the local assembly, please check whether the device and circuit assembly assembly process correctly.

Default of banned in the streets, highways, landslides and other dangerous places.

Children must be under the custody of adult use.

When used on the local, please do not casually change device.

When use, shall not be frequently switch forward backward function.

Please check the battery, line, plugs, and other parts for damage and found damaged, please stop using in time.

Until the restored can be reused.

The rechargeable battery can't charge.

Should be in the right electrode in the battery.

Run out of battery should be removed from the toy.

The power terminals shall not be short

Charging matters needing attention

1, using electric vehicles for the first time to charge first! Charging in car tail, charging charging Cover first then put the plug in the charging socket, then the charger plugged in. (charging must Be made into do, do not let your children's access to power supply)

2, please recharge immediately when electric vehicle driving speed slowed significantly, continuous Charging 8 to 10 hours, not more than 10 small at the right time.

3, in the process of charging the charger or battery have lever phenomenon (under 60 °) are Normal.

4, the electric car must use local car equipped with dedicated charger and battery, so as not to Damage the charger and battery and electric circuit.

5, the electric vehicle charging shall not do any operation.

6, please a mixture of old and new or different types of batteries.

7, electric vehicle charging, please check whether the circuit connection is correct.


8, when the electric conductor time when not in use, must charge at least once every month.

Warning: electric car used in non private places, may lead to drowning, burns, falls and other hazards.

ELECTRIC CAR


Install and use the manual

Manual has an important information, read, please keep for future reference.




STANDARDS:EN71、EN62115

UNIT MOUNT




Install the steering wheel

Will line connectors and direction in the direction of dish stem line connectors are connected (note that connect the positive and negative). Then put the steering wheel in the direction of the pole, with the M5 inner hexagonal set screw rod through the steering wheel and direction in turn. (as shown in figure 4)



Charging instructions


Before installing seat first connect the positive, and then put seat in the specified location, card hook body card slot, then put the front seat fixed on both sides of the hole with the screw clockwise tightened when charging, open cover charge first, and then insert the charger to charge hole, when charging the vehicle without any function. (as shown in figure 5)



Remote control battery installation

First use the screwdriver to unscrew the screw on the battery cover, then take out the battery cover and remote control into two AA1.5 V batteries, and battery cover cover and screw locking. (see figure 6)

Install know that



1 first open the key to the total power supply, the lights lit up and accompanied by the start of the sound.2 move the steering wheel button, this time the music rings. Sound size adjustment will be up and down the first switch key press, can be achieved.3 the upper left corner of the music board is MP3 interface, the following is the memory card insertion port and next to the USB jack.4 point move "story /V+" key, this time for the story mode.5 "music /V-" button, at this time for the song mode.6 point move "ancient poetry / play" key, this time for the ancient poetry mode.7 "early" button, this time for early education mode.8 point "horn" key, this time for the speaker mode.9 "forward and backward" switch forward gear, step on the pedal switch car forward. Will "go back" after the switch back, step on the foot switch the car to run backwards. 11 the red circular switch is the swing start button, and the switch can realize the swing function.

(as shown in Figure 7)

USE CAUTIONS

- 1 In the first to use the deposit, we must ensure that the cell battery up to 10 hours, otherwise, permanent damage cells and beyond repair.
- 2 Charging socket the cushion down side, and needs recharging, charger plug in the outlet, then insert the power outlet.
- 3 The rain sun slowly, in charge, the time for 8-10 hours, and not more than ten hours.
- 4 In the first to use the deposit, we must ensure that the cell battery up to 10 hours, otherwise, permanent damage cells and beyond repair.
- 5 Don't run in an electric switch on deposits in the back of the light switch.
- 6 Shall not be altered the car circuit or device to additional charged
- 7 The remote control and not to let it get caught in the rain or otherwise
- 8 Met with obstruction, the baby stop, please leave the obstacles to ride.
- 9 Don't use in the water, water and other liquids in the car.
- 10 Not in use, to avoid hitting the child.
- 11 When the remote control battery power is low, the car on the remote control and turned back, a short distance, shake, please replace the battery!
- 12 Not in use, please turn off the switch, no, please unplugging the battery, a part of the structure, and appearance.
- 13 The types of batteries that may be used.
- 14 How to remove and insert the batteries.
- 15 Non-rechargeable batteries are not to be recharged.
- 16 Rechargeable batteries are a battery charger for use by children, supervision/for toys supplied with a battery charger for use by children, this in function may be replaced by: " Batteries are only to be charged by adults or by children at least 8 years old."
- 17 Rechargeable batteries are to be removed from the toy before being charged.
- 18 Different types of batteries or new and used batteries are not to be mixed.
- 19 Batteries are to be inserted with the correct polarity.

CHARGE METHOD

- 1 First to use please open the cushion , and the battery connections with main distributing frame; with red in red and black in black, not a fine ends meet, or cause a short-circuit.
- 2 Charging socket the cushion down side, and needs recharging, charger plug in the outlet, then insert the power outlet.
- 3 The rain sun slowly, in charge, the time for 8-10 hours, and not more than ten hours.
- 4 In the first to use the deposit, we must ensure that the cell battery up to 10 hours, otherwise, permanent damage cells and beyond repair.
- 5 Don't run in an electric switch on deposits in the back of the light switch.
- 6 Shall not be altered the car circuit or device to additional charged
- 7 The remote control and not to let it get caught in the rain or otherwise
- 8 Met with obstruction, the baby stop, please leave the obstacles to ride.
- 9 Don't use in the water, water and other liquids in the car.
- 10 Not in use, to avoid hitting the child.
- 11 When the remote control battery power is low, the car on the remote control and turned back, a short distance, shake, please replace the battery!
- 12 Not in use, please turn off the switch, no, please unplugging the battery, a part of the structure, and appearance.
- 13 The types of batteries that may be used.
- 14 How to remove and insert the batteries.
- 15 Non-rechargeable batteries are not to be recharged.
- 16 Rechargeable batteries are a battery charger for use by children, supervision/for toys supplied with a battery charger for use by children, this in function may be replaced by: " Batteries are only to be charged by adults or by children at least 8 years old."
- 17 Rechargeable batteries are to be removed from the toy before being charged.
- 18 Different types of batteries or new and used batteries are not to be mixed.
- 19 Batteries are to be inserted with the correct polarity.

PACKING LIST

★ Car body (polypropylene)	1PC
★ Charger	1PC
★ The steering wheel	1PC
★ Manual	1PC
★ Remote controller	1PC
★ Car wheel, blocks	4PCS

DECLARATION:

1)Manual used in illustrations to explain the product of the operations and product, with the installation of structure in the existence of a small difference in kind, please standard the object.

2)In order to improve product quality, not to notice, we may change the part of the structure, and appearance.

3)This package contains important information that must be kept.

4)Cannot be used in rainy days.

5)Can not use water to clean.

6) Assembly by an adult."

7) Protective equipment should be worn. Not to be used in traffic."

8) Driving, we must by adults, don't let the children touch.

9 Clamp down on the streets, roads, slopes, waiting for over a backward, to eliminate obstacles to ride.

10 It's suitable for children for about 3-7-96 months.

11 Cycle shall not leave the seat to prevent operation resulting in injury.

12 Please do not use in the streets, roads, landslides and other dangerous places, and must be used under adult guardianship.

13 Safe use period: three years.

14 Children must use under adult supervision.

15 When not in use for a long time, please turn the power off and remove the battery connector.

16 Please check the product and the charger, check the wires, plugs, shell packaging and other avoid damage to electric vehicles.

17 Running stand to do some dangerous action.

18 Please listen your seat belt, and make sure that your baby is always sit on the bench, at the same time, please do not let the baby in.

19 This product is limited to a person, do not overload, the largest capacity of 30 kg.

20 to use under adult supervision.

21 Please don't in the street, the road, landslides and other dangerous places, and be sure Pool and beyond repair.

22 It would be permanent damage.

23 The first use of electric vehicles, must ensure that the battery full 10 hours! Otherwise using this product.

24 Battery charging should be carried out by adults, must first be charged before Products should be assembled by adult right before use.

25 Manual should be placed to take good care of.

26 It's STANDARD NO.:EN71 EN62115

27 The product to get is the main ingredients of the important parts.

28 Use the product please first read instructions, it will tell you the correct methods of operation and installation instructions. To avoid not correct methods of operation of this product damage or injury and your baby.

29 The supply terminals are not to be short-circuited.

30 Exhausted batteries are to be removed from the toy.

Using The Matters Needing Attention

Products should be assembled by adult right before use.

Battery charging should be carried out by adults, must first be charged before using this product.

It would be permanent damage.

Please don't in the street, the road, landslides and other dangerous places, and be sure Pool and beyond repair.

to use under adult supervision.

This product is limited to a person, do not overload, the largest capacity of 30 kg.

Please listen your seat belt, and make sure that your baby is always sit on the bench, at the same time, please do not let the baby in.

Running stand to do some dangerous action.

Please don't suddenly change in the process of electric vehicles turn forward backward with avoid damage to electric vehicles.

Please check the product and the charger, check the wires, plugs, shell packaging and other components

Damage, found that the damage should stop using, to be repaired before use.

When not in use for a long time, please turn the power off and remove the battery connector.

Safe use period: three years.

Please do not use in the streets, roads, landslides and other dangerous places, and must be used under adult guardianship.

The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.