
















NS7055 TV Stand




<p>A</p>  <p>a1</p>  <p>a2</p> <p>x28</p>	<p>B</p>  <p>∅8*30mm</p> <p>x34</p>	<p>C</p>  <p>x2</p>	<p>D</p>  <p>x30</p>
<p>E</p>  <p>x4</p>	<p>F</p>  <p>x8</p>	<p>G</p>  <p>x4</p>	<p>H</p>  <p>∅4*16mm</p> <p>x24</p>
<p>I</p>  <p>x4</p>	<p>J</p>  <p>x1</p>	<p>K</p>  <p>∅3.5*35mm</p> <p>x8</p>	<p>L</p>  <p>∅3.5*14mm</p> <p>x16</p>


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

