






# ASSEMBLY INSTRUCTION

Thank you for your purchase. Please follow the instructions below for correct assembly.


1		1PC	6		2PCS
2		1PC	7		1PC
3		1PC	8		1PC
4		1PC	9		4PCS
			10		1PC
			A	 3.5*40MM	12PCS
			B	 3.0*25MM	4PCS
5		1PC	C	 3.0*35MM	6PCS

Step 1:




Attach part⑦ and part⑧ to part⑨, secure 4x part⑨ each with 1x screw(B) as pictured. Note: part⑦ and part⑧ are detachable entrance, not fixed.

Step 2:




Secure left panel part⑤, middle panel part③ and right panel part④ by each using 2x screw(A), total 6x screw (A).

Step 3:




Put in 2x floor panel part⑥ as shown.

Step 4:



Secure back panel part② by using 6x screw (A).

Step 5:



Attach part⑩ to the top, secure with 6x screw(C).

# **RETURN / DAMAGE CLAIM INSTRUCTIONS**

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: [sales@tsbliving.co.nz](mailto:sales@tsbliving.co.nz)

Christchurch Branch: [customersupport@tsbliving.co.nz](mailto:customersupport@tsbliving.co.nz)

Wellington Branch: [wellington@tsbliving.co.nz](mailto:wellington@tsbliving.co.nz)