

PR 6094

Zero Gravity Chair Black Oxford



SAFETY

- Occasional outdoor furniture for domestic use.
- Maximum weight loading 110kg per chair .
- Always place the seat on a firm level base and ensure that the chair legs remain in contact with the ground at all times.
- Do not use without the plastic feet attached or with armrests and leg hinges in the locked position.
- Do not stand on this relaxer or sit on the arms.
- Take care when opening or adjusting; keep hands away from moving parts in order to prevent injury.
- Children using the chair should be closely supervised by an adult.
- Please read the instructions and guidance carefully to ensure safe use of this product.
- Plastic bags can be dangerous. To avoid danger of suffocation keep bags away from babies and children.
- Do not use this product if any parts appeared to be damaged or missing.

CARE & MAINTENANCE

- To clean, wipe with mild soap and water, rinse thoroughly. Do not use bleach, acid, solvents or abrasive cleaners on this item. Spot check a small area first. Dry completely.
- The product you have purchased is constructed from high quality steel for strength and durability. Most metal is prone to some corrosion over time and you can expect this to occur on outdoor furniture, particularly if you intend to leave the furniture exposed to weather for periods of time. Consequently this product is not guaranteed against corrosion, there are some measures you can take to minimise this:
- Wash the metal parts on a regular basis. And then use car polish or a similar product to provide extra protection.
- On metal furniture, rain water can seep into the frame and cause some internal rusting; rusty water may then leak from the frame. Periodically empty water from the frame to avoid staining to your patio or decking.
- If the painted finish should become chipped or scratched exposing bare metal, remove any surface rust and treat with a touch up paint.
- If the furniture is not being used for long periods or during the winter, store inside or under a suitable cover. Before putting into storage, insure the item is clean and dry.

STEPS

1. After removing this item from its packaging , place the back leg of the chair on the ground/floor and hold as shown in Fig.1
2. Unfold the chair - Holding the chair by the backrest tube in one hand, exert outward and downward pressure on the armrest with your other hand , this will cause the chair to open as indicated in Fig.2 & 3 below. Be careful not to trap or pinch your fingers in the moving parts of the chair.
3. Placing one foot on the rear leg, slide the backrest back fully and then forward into the most upright position - Fig 4. Ensure that the front and back legs are in the fully extended position by checking that the back leg hinge and bracket are in the correct position as shown in Fig. 4a & 4b below. The chair must not be used unless these parts are in the correct position.
4. Before sitting on the chair , ensure that the front legrest is in the most upright position so that it is almost tipping the ground Fig.5
5. To recline the chair : hold the front of the armrests in each hand and slowly lean backward to the required position. Lock the chair in position by turning the locking knobs in the direction indicated. See Fig. 6 & 7.
6. When you are finished using the chair , simply turn the knob in the required direction to unlock. Place both hands on the front of the armrest and lean forward. This will bring the chair back to the most upright position. See Fig.8
7. To fold the chair, reverse steps 1-3 above, taking care not to trap or pinch your fingers in the folding action of the chair.

