



### Assembly Step 3.


















1. Attach H to D 2PCS using ⑥ 4pcs to secure them.

2. Attach I to E 2PCS using ⑥ 4pcs to secure them.




## PART LIST

<p>A. Base Tube 1</p>  <p style="text-align: right;">x 1</p>	<p>B. Main Frame</p>  <p style="text-align: right;">x 2</p>	<p>C. Base Tube 2</p>  <p style="text-align: right;">x 1</p>
<p>D. Seat Support</p>  <p style="text-align: right;">x 2</p>	<p>E. Backrest Support</p>  <p style="text-align: right;">x 2</p>	<p>F. Seat Adjustment Bar</p>  <p style="text-align: right;">x 1</p>
<p>G. Backrest Adjustment Bar</p>  <p style="text-align: right;">x 1</p>	<p>H. Seat Pad</p>  <p style="text-align: right;">x 1</p>	<p>I. Backrest Board</p>  <p style="text-align: right;">x 1</p>
<p>① M10 x 65 Countersunk head bolt nut, washers</p>  <p style="text-align: right;">x 2</p>	<p>② M10 x 65 bolt, nut, washers</p>  <p style="text-align: right;">x 2</p>	<p>③ M10 x 130 bolt nut, washers</p>  <p style="text-align: right;">x 1</p>
<p>④ M10 x 180 bolt, nut, washers</p>  <p style="text-align: right;">x 1</p>	<p>⑤ M10 x 180 bolt, nut, washers</p>  <p style="text-align: right;">x 1</p>	<p>⑥ M8 x 40 bolt, washer</p>  <p style="text-align: right;">x 8</p>

1


## Assembly Step 1.

1. Connect A to B using ① 2pcs to secure them.
2. Connect C to B using ② 2pcs to secure them.



## Assembly Step 2.

1. Attach D 2PCS to F using ③ 1pcs to secure them.
2. Attach E 2PCS to G using ⑤ 1pcs to secure them.
3. Attach D F E G to B using ④ 1pcs to secure them.



2